


# BUTTON MAKER INSTRUCTIONS

For each button, you'll need:

- button shell/top
- your artwork (precut into circles)
- mylar sheet (circle)
- pin back



Trim your artwork into circles, using the matching 1.25" or 2.25" button template.

Insert a metal button shell in the left side die, rim side down.

Next, place artwork on top of shell with print side up and a sheet of mylar on top of artwork.



Slide left die under the press and push handle down. Button top will stay inside machine.



Insert pin back, pin side down, in right side die. Be sure pin orientation matches button top.



Slide right die under the press and push handle down to complete your pin.

# PUNCH CUTTER INSTRUCTIONS



© www.AmericanButtonMachines.com

**Please Note:** No special paper is required to make a pinback button. Simply cut regular printer paper into strips.

Follow the instructions below to learn how to use a punch cutter:



1. Insert the paper strip into the punch cutter and center the graphic in the hole.
2. Push the handle down until the punch goes all the way through the paper.
3. Remove the cut graphic and place to the side.
4. Pull the paper strip through, center the next graphic, and repeat steps 2 and 3.

For an instructional video visit: <https://www.youtube.com/watch?v=YGW5tXpPIjU>



Visit [www.herrickdl.org/library-of-things](http://www.herrickdl.org/library-of-things) for button making resources and to download button templates.