

## Instructions

### Product Description:

- \* Product is tray loading external portable ODD caddy which is suitable to USB 2.0/3.0 connector desktop or laptop,
- \* Compatible Windows 7/8/10/XP/2003/Vista/Linux, mac 10 OS system
- \* No extra drive, support plug and play.
- \* Compatible USB3.0 port and the following parts USB2.0/1.1 efficiency more stable. Applies more widely.
- \* Data cable with pure copper braid process, anti-interference ability, signal attenuation, more stable data transmission.
- \* The applicable standard SATA ODD.
- \* Power consumption 3-5W.

### Instructions

\*Please note this DVD/CD drive only directly supports Window 7 burn. For other operating system, please download the "Burn software" before apply this burning function!

\* Products through standard USB data cable to the computer USB port properly connected, the computer monitor should appear in the lower-right corner of the icon. Click "My Computer" on the desktop should be displayed in the removable storage devices.

\* Click on this icon, right-click and select "pop-up" in the tray into the disc to read.

\* Internal laser light source may be harmful to the eyes of the face. Please do not look directly.

\* Do not have the machine on a strong magnetic objects nearby.

\* Keep the machine steady on the desktop, do not put it unstable items.

Please install "VLC Media Player" on computer for Mac series device in case of failure recognition with this drive.

\* Don't put the machines on the vulnerable to squeeze place, to ensure normal machine use.

## Possible Problems & Solutions

1. If you are using a desktop, it may not work if you try to plug the CD drive in front of the USB interface.(Pic 1). We suggest you to use the USB port at the back.(Pic 2).




Pic 1



Pic 2

2. You can only connect the device directly through the USB port of your laptop instead of trying to use USB hubs (in pic 1) in case of lack of power supply and cause the device not recognisable.



Pic 1



Pic 2

3. If you have done the former steps properly and there is still problem with recognize your CD or DVD, it's possible that the slots of the drive is unfastened(like pic 1). What you need to do is to push it again until the device shows as pic 2.



Pic 1




Pic 2

4. If you are using Apple computers and you need extra USB port or using extension cords, the device will only work by using the cable-free transfer like pic 1 shows.



Pic 1



Pic 2

5. Please note that the device can not read or write Blu-ray CD DVD.  
6. If you do not encounter any of above issues, and your computer is brand new, then you might need to download and install a CD driver software for normal use.

## Precautions

The external device can work depends on the operating system on your computer whether has the capabilities to detect devices, otherwise, you would need to download a driver.

Almost all of the older operating systems include programming that allows them to recognize a DVD - RW being installed directly or being connected externally. So if the operating system on your computer has the drivers or the ability to download drivers, it will allow the external CD/DVD drive work.

### Anomalies Solutions

- \* Please make sure your computer have downloaded CD/DVD driver before using the CD-ROM drive. We could send you the link to download the driver.
- \* Please make sure the laptop is with sufficient capacity, a low capacity may cause the device can't be recognized.
- \* The new released Windows system have discontinued the internal DVD media player software, customer using Windows 10 and above are advised to install VLA Media Player to Play DVD and CD.
- \* Please hook up the device to the direct USB port on your computer. If you connect it to a USB hub or extension cords, it may cannot recognize the device or cannot read the CD/DVD.